


Food Safety in Your Home

Focus on Slow Cooker Safety

Opening the front door on a cold winter evening and being greeted by the inviting smells of beef stew or chicken noodle soup wafting from a slow cooker can be a diner's dream come true. But winter is not the only time a slow cooker is useful. In the summer, using this small appliance can avoid introducing heat from a hot oven. At any time of year, a slow cooker can make life a little more convenient because by planning ahead, you save time later. And it takes less electricity to use a slow cooker rather than an oven.



Is A Slow Cooker Safe?

Yes, the slow cooker, a countertop appliance, cooks foods slowly at a low temperature – generally between 170° and 280° F. The direct heat from the pot, lengthy cooking time, and steam created within the tightly-covered container combine to destroy bacteria and make the slow cooker a safe process for cooking foods. And the low heat helps less expensive, leaner cuts of meat become tender.

Safe Beginnings


Begin with a clean cooker, clean utensils and a clean work area. Wash hands before and during food preparation. Keep perishable foods refrigerated until preparation time. If you cut up meat and vegetables in advance, store them separately in the refrigerator. The slow cooker may take several hours to reach a safe, bacteria-killing temperature. Constant refrigeration assures that bacteria, which multiply rapidly at room temperature, won't get a "head start" during the first few hours of cooking.

Thaw & Cut Up Ingredients

Always defrost meat or poultry before putting it into a slow cooker. Cut food into chunks or small pieces to ensure thorough cooking. Do not use the slow cooker for large pieces like a roast or whole chicken because the food will cook so slowly it could remain in the bacterial "danger zone" too long.

Settings

Most cookers have two or more settings. Foods take different times to cook depending upon the setting used. Certainly, foods will cook faster on high than on low. However, for all-day cooking or for less-tender cuts, you may want to use the low setting.



If possible, turn the cooker on the highest setting for the first hour of cooking time and then to low or the setting called for in your recipe. However, it's safe to cook foods on low the entire time – if you're leaving for work, for example, and preparation time is limited.

Use the Right Amount of Food

Fill cooker no less than half full and no more than two-thirds full. Put vegetables in first, at the bottom and around the sides. Then add meat and cover the food with liquid such as broth, water or barbecue sauce. Keep the lid in place, removing only to stir the food or check for doneness.

Handling Leftovers

Store leftovers in shallow covered containers and refrigerate within two hours after cooking is finished. Reheating leftovers in a slow cooker is **not recommended**. However, cooked food can be brought to steaming on the stove top and then put into a preheated slow cooker to keep hot for serving.